



PLUG N DIKE PREMIX - INSTRUCTIONS

NO SURFACE PREPARATION IS NECESSARY. PLUG THE LEAK EVEN IF SURFACE IS DIRTY AND HAS FLUID FLOWING OVER IT

1. Put on the latex gloves. Take a handful of Plug N Dike and apply it directly into and around the edges of the leak. Work it and press down to get good adhesion.
2. Apply enough Plug N Dike to get a good thick layer over the leak. Additional Plug N Dike can be added over the top. Not for use on urethane or Teflon surfaces.
3. Will hold up to 2-3 feet of head. Plug N Dike is only a temporary plug.

Non-toxic and non-flammable.

Store above freezing unless using the Plug N Dike Low-Temp.

Not recommended for use plugging containers of antifreeze, acids, bases, or oxidizers.

Non-warranty: The above suggestions and data are based on work done in the lab and field results. Because the storage, handling, and application are beyond our control, the manufacturer and seller accept no liability for the results obtained.